

MSG 076 - RED FD06 SOLSE PROCEDURE CHANGES

- 1) Change the following SOLSE procedures to account for increased time for PGSC to receive LORE packets. In all procedure pages listed below make the following changes:

WAS: After 1 min 45 sec,
IS: After 3 min,

SOLSE HEALTH CHECK p.1-14
SOLSE SETUP p. 1-24
SOLSE CONTINGENCY RECOVERY p 1-52

WAS: * If after 1 min 45 sec, LORE Packets Rcvd=0 *
IS: * If after 3 min, LORE Packets Rcvd=0 *

SOLSE HEALTH CHECK p.1-14
SOLSE SETUP p. 1-24

Rationale: LORE is taking longer than expected to transfer files internally immediately following power-up. Not a concern at this time.

- 2) Change the following SOLSE procedure on the page listed

SOLSE SCIENCE p. 1-28, step 2.
DELETE: √ Heater & Door Power – ON

Change the following SOLSE procedure on the page listed, after “ √ HRIU Status – initialized “

SOLSE SCIENCE p. 1-31, step 6, after “ √ HRIU Status – initialized “
ADD: √ Heater & Door Power – ON
ADD: * If Heater & Door Power – OFF *
ADD: * Heater & Door Power – ENAB (√ ON) *